



ATLAS DIGITAL SERVO SPECIFICATIONS

Parts and Accessories

Servo #	Full Gear Set	Primary (4 pcs) Gear Set	Stock Horns	Accessory Horns	Accessory Horns	Accessory Horns	Screw Set
DS09-AMD	DS09GEAR-AMD	DS09-AMD-GP4	DS0911HORN-B	DS11HORNLS	DS11HORNAL-S		DS-HORNSCREW
DS09-GMD	DS09GEAR-GMD	DS09-GMD-GP4	DS0911HORN-B	DS11HORNLS	DS11HORNAL-S		DS-HORNSCREW
DS09-SCD	DS09GEAR-SCD	DS09-SCD-GP4	DS0911HORN-B	DS11HORNLS	DS11HORNAL-S		DS-HORNSCREW
DS09-SMD	DS09GEAR-SMD	DS09-AMD-GP4	DS0911HORN-B	DS11HORNLS	DS11HORNAL-S		DS-HORNSCREW
DS095-FMD	DS095GEAR-FMD	DS095-FMD-GP4	DS095HORN	DS095HORNAL-S			DS-HORNSCREW
DS11-AMB	DS11GEAR-AMB	DS11-AMB-GP4	DS0911HORN-B	DS11HORNLS	DS11HORNAL-S		DS-HORNSCREW
DS11-GCB	DS11GEAR-GCB	DS11-GCB-GP4	DS0911HORN-B	DS11HORNLS	DS11HORNAL-S		DS-HORNSCREW
DS11-SCB	DS11GEAR-SCB	DS11-SCB-GP4	DS0911HORN-B	DS11HORNLS	DS11HORNAL-S		DS-HORNSCREW
DS12-ACP	DS12GEAR-ACP	n/a	DS1213HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS12-GCP	DS12GEAR-GCP	n/a	DS1213HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS12-HCP	DS12GEAR-HCP	n/a	DS1213HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS12-SCP	DS12GEAR-SCP	n/a	DS1213HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS13-ACB	DS13GEAR-ACB-B	n/a	DS1213HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS13-TCB	DS13GEAR-TCB-B	n/a	DS1213HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS13-TMB	DS13GEAR-TMB-B	DS13-TMB-GP4	DS1213HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS13-GCB	DS13GEAR-GCB	DS13-GCB-GP4	DS1213HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS16-FCD	DS16GEAR-FCD	n/a	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS16-FMD	DS16GEAR-FMD	DS16-FMD-GP4	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS20-FMD	DS20GEAR-FMD	DS20-A-GP4	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS20-GMD	DS20GEAR-GMD	DS20-GMD-GP4	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS20-HMD	DS20GEAR-HMD	DS20-A-GP4	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS20-SMD	DS20GEAR-SMD	DS20-A-GP4	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS20-UMD	DS20GEAR-UMD	DS20-A-GP4	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS20X-SMD	DS20xGEAR-SMD	DS20x-SMD-GP4	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS20X-TMD	DS20xGEAR-TMD	DS20x-TMD-GP4	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DS20X-GCD	DS20xGEAR-GCD	n/a	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DH13-GCB	DS13GEAR-ACB-B	n/a	DS1213HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DH13-FMB	DH13GEAR-FMB	DS13-TMB-GP4	DS1213HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DH13-FTB	DH13GEAR-FTB	DS13-TMB-GP4	DS1213HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DH16-SCD	DH16GEAR-SCD	n/a	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DH16-FMD	DS16GEAR-FMD	DS16-FMD-GP4	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DH16-GCD	DH16GEAR-GCD	n/a	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DH16-FTD	DH16GEAR-FTD	DS16-FMD-GP4	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DH20-FCD	DH20GEAR-FCD	n/a	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DH20-UCD	DH20GEAR-UCD	n/a	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DH20-FTD	DH20GEAR-FTD	DH20-FTD-GP4	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DH20-UTD	DH20GEAR-UTD	DH20-UTD-GP4	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DH20X-SCD	DH20xGEAR-SCD	n/a	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW
DH20X-GCD	DS20xGEAR-GCD	DS20x-GCD-GP4	DS20HORN	DSHORNHD-F	DSHORNAL-D	DSHORNAL-S	DS-HORNSCREW